IMPORTANT SAFEGUARDS AND PRECAUTIONS FOR CAMCORDER

- Do not aim the camcorder lens (or set the camcorder in a position) toward the sun or other extremely bright light sources or objects, whether the camcorder is turned on or off. This could permanently damage the imaging tube.
- Read/Retain Instructions and Original Packaging—Read all the safety and operating instructions before the equipment is operated and retain for future reference. Also retain the original packaging in case your equipment requires service.
- Cleaning—Do not use liquid cleaners or aerosol cleaners. To clean external parts, use a damp cloth. NEVER clean anything located inside your camcorder. If you believe internal cleaning is necessary, take your camcorder to your dealer or a Kodak Service Center. See the Service section in this User's Guide for details.
- Attachments—Use attachments recommended for use with KODAVISION Products only.
- Object or Liquid Entry—Do not push objects of any kind into equipment openings. If objects or liquids have fallen into your camcorder, take your camcorder back to your dealer for servicing.
- Do not transport your camcorder in the optional cradle.
- Servicing—Do not attempt to service this equipment. This will void the warranty. Opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel. Avoid striking, shaking, etc. The camcorder contains a sensitive imaging tube which could be damaged by improper handling or storage.
- Avoid sudden changes in temperature. If your camcorder is suddenly moved from a cold to a warm place, moisture may form in the cassette and inside the camcorder. Do not store your camcorder in conditions where temperatures are over 131°F (55°C). The temperature range to ensure proper operation is 40°F (5°C) to 104°F (40°C).
- Do not bring a strong magnet or magnetized object near your camcorder and tapes. It will harm their performance.
- Do not leave your camcorder turned on when not in use.
- Do not turn the power on and off repeatedly without use.
- Warning! The KODAVISION Battery contains sulfuric acid. Do not cut, crush, heat, burn, or short circuit. Avoid skin and eye contact with internal contents. This battery is to be used only with KODAVISION Products; other batteries should not be used. Recharge only with a charging device recommended for use with KODAVISION Batteries.

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE CAMERA OR POWER SUPPLY TO RAIN OR MOISTURE.

The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure; that may be of sufficient magnitude to constitute a risk of electric shock to persons.

CAUTION

RISK OF ELECTRIC SHOCK
DO NOT OPEN

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

Consumer/Professional & Finishing Markets

EASTMAN KODAK COMPANY • ROCHESTER, NEW YORK 14650

IMPORTANT SAFEGUARDS AND
PRECAUTIONS FOR CAMCORDER
Part No. **633734a**

M4H074 Minor Revision-9-84-BE
Printed in United States of America